







How to change rear coil springs on VW Touran 1T1 1T2 – replacement guide



VIDEO TUTORIAL

(i) Important!

This replacement procedure can be used for: VW TOURAN (1T1, 1T2) 2.0 TDI

The steps may slightly vary depending on the car design.

WWW.AUTODOC.CO.UK 1–23



REPLACEMENT: COIL SPRINGS – VW TOURAN 1T1 1T2. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Drive socket # 18
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Hammer
- Crow bar
- Hydraulic transmission jack
- Wheel chock

WWW.AUTODOC.CO.UK 2–23




Replacement: coil springs – VW Touran 1T1 1T2. AUTODOC experts recommend:

- Both coil springs of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right coil springs of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: COIL SPRINGS – VW TOURAN 1T1 1T2. USE THE FOLLOWING PROCEDURE:

1



Secure the wheels with chocks.

WWW.AUTODOC.CO.UK 3–23





Loosen the wheel mounting bolts. Use wheel impact socket #17.

3



Raise the rear of the car and secure on supports.

WWW.AUTODOC.CO.UK 4–23





Unscrew the wheel bolts.

AUTODOC recommends:

 Important! Hold the wheel while unscrewing the fastening bolts. VW Touran 1T1 1T2

5




Remove the wheel.

WWW.AUTODOC.CO.UK 5–23



Clean all joints of the arm. Use a wire brush. Use WD-40 spray.

7



Make a mark on the camber adjustment bolt.

WWW.AUTODOC.CO.UK 6–23



Unscrew the arm fastening to the beam. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.


9



Support the arm. Use a hydraulic transmission jack.

WWW.AUTODOC.CO.UK 7–23





Clean the exhaust system fastener. Use WD-40 spray.

11



Remove the exhaust system fastener. Use a crowbar.

WWW.AUTODOC.CO.UK 8–23



Remove the fastening bolt. Use a crowbar. Use a hammer.

13



Remove the support from under the arm.

AUTODOC recommends:

 Replacement: coil springs – VW Touran 1T1 1T2. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

WWW.AUTODOC.CO.UK 9–23



Take out the spring.

15



Clean the coil spring mounting seats. Use a wire brush. Use WD-40 spray.

WWW.AUTODOC.CO.UK 10-23





Install the rubber spacer on the new coil spring.

17



Install the coil spring together with the rubber mounts into the mounting seats.

WWW.AUTODOC.CO.UK 11–23





Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.

19



Support the arm. Use a hydraulic transmission jack.

WWW.AUTODOC.CO.UK 12–23






Install the fastening bolt.

Replacement: coil springs – VW Touran 1T1 1T2. Professionals recommend:

• Adjust the position of the alignment bolt according to the mark.

21



Remove the support from under the arm.

WWW.AUTODOC.CO.UK 13–23



AUTODOC recommends:

 Replacement: coil springs – VW Touran 1T1 1T2. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

22



Tighten the fastener connecting the control arm to the rear subframe. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 95 Nm torque.

23



Clean the exhaust system fastener. Use WD-40 spray.

WWW.AUTODOC.CO.UK 14–23



Install the exhaust system fastener.

25



Treat all joints of the arm. Use copper grease.

WWW.AUTODOC.CO.UK 15–23





Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

27



Clean the brake disk surface. Use a brake cleaner.

AUTODOC recommends:

• Replacement: coil springs – VW Touran 1T1 1T2. After applying the spray, wait a few minutes.

WWW.AUTODOC.CO.UK 16–23






Install the wheel.

AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Touran 1T1 1T2

29



Screw in the wheel bolts. Use wheel impact socket #17.

WWW.AUTODOC.CO.UK 17–23





Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 nm torque.

31



Remove the jacks and chocks.

WWW.AUTODOC.CO.UK 18–23



DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES

NO




BECOME A MEMBER OF AUTODOC CLUB!

WWW.AUTODOC.CO.UK 19–23




AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE





WWW.AUTODOC.CO.UK 20–23







WWW.AUTODOC.CO.UK 21–23







WWW.AUTODOC.CO.UK 22–23





i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.

WWW.AUTODOC.CO.UK 23–23